

# **IMPORTANT “READ FIRST”**

**IT IS IMPORTANT TO CHARGE THE BATTERY FULLY BEFORE USING. IF THE BATTERY GAUGE DOESN'T APPEAR AT FIRST TO REPORT THE BATTERY LEVEL ACCURATELY, IT WILL AFTER A FEW CHARGE / DISCHARGE CYCLES.**

**7001-31075-900 REV.05-17**